

**TURTLE**  
By Perini-A-Store



## Turtle Media Cases

Now Including Brass Combination Padlock As Standard.

Providing secure storage for media while it is being transported can be achieved using Turtle media cases.

Turtle media cases are specially designed to protect the stored media during storage and transportation, and protect from mechanical impacts, temperature and / or humidity extremes, debris from foreign contaminants, airborne debris and electrostatic discharge.

### Features & Benefits

- A double wall construction that absorbs impact so reducing shock to tapes. The double wall construction also provides insulation from external temperature changes, protects from mechanical loads that would distort the cartridge shape and minimises the effects of stray magnetic fields.
- Made from a special high density polyethylene construction that is lightweight but incredibly durable. The material will not rust and there are no sharp edges.
- The unique molded dividers create individual media specific slots, that are sized to the exact dimensions of each media type. This reduces damage to the media that could be caused by shaking and rattling.
- The sealing on Turtle cases prevents the ingress of dirt and water, and also prevents condensation.
- Turtle cases have self locking, double strong latches that are sturdy and safe from springing open.
- Lockable for added security (Brass combination padlock now included as standard).
- Recessed smooth grip handles that are easy to carry and easy to stack.
- Available for DLT, SDLT, LTO, 4mm, 8mm and more.

### LTO / Ultrium Cases



**LTO Mailer**  
77-TC-LTO-1



**LTO 5 Capacity**  
77-TC-LTO-5



**LTO 20 Capacity**  
77-TC-LTO-20

### DLT / SDLT Cases



**DLT Mailer**  
77-TC-DLT-1



**DLT 5 Capacity**  
77-TC-DLT-5



**DLT 14 Capacity**  
77-TC-DLT-14



**DLT 20 Capacity**  
77-TC-DLT-20

## Multipurpose Cases



**Mini Multi**  
77-TC-MINI-MULTI



**Mid Multi**  
77-TC-MIDI-MULTI



**Ulti Multi**  
77-TC-ULTI-MULTI

## 9840 / 9940 / T10000 Cases



**9840 / 9940 /  
T10000 - 20 Capacity**  
77-TC-9840-20

## 3592 Cases



**3592 - 20 Capacity**  
77-TC-3592-20

## Specifications

Part Number	Dimensions (L x W x H)	Weight	Colour	Lockable
77-TC-LTO-5	286mm x 210mm x 140mm	1.3Kg	Blue	Via Padlock*
77-TC-LTO-20	445mm x 362mm x 159mm	3.2Kg	Black	Via Padlock*
77-TC-DLT-5	286mm x 210mm x 140mm	1.2Kg	Red	Via Padlock*
77-TC-DLT-14	394mm x 337mm x 152mm	2.7Kg	Red	Via Padlock*
77-TC-DLT-20	445mm x 362mm x 159mm	3.6Kg	Red	Via Padlock*
77-TC-MINI-MULTI	286mm x 210mm x 140mm	1.4Kg	Blue	Via Padlock*
77-TC-MIDI-MULTI	394mm x 337mm x 152mm	2.4Kg	Red	Via Padlock*
77-TC-ULTI-MULTI	508mm x 406mm x 178mm	3.2Kg	Red	Via Padlock*
77-TC-9840-20	445mm x 362mm x 159mm	3.6Kg	Red	Via Padlock*
77-TC-3592-20	445mm x 362mm x 159mm	3.2Kg	Black	Via Padlock*

\* Brass combination padlock now included as standard.

## Cases also available for:



**4mm / DAT  
/ DDS**



**8mm / AIT  
/ VXA**



**3480 / 3490  
/ 3590**



**3570**



**Hard Drives**