

KASO PK-400 MEDIA FIRE SAFES

- Certified fire and burglary protection for data and media -



- 120 minutes fire protection for data according to NT FIRE 017 - 120 Diskette
- Burglary protection S1 according to European Standard EN 14450 (ECB-S)

KASO PK-400 MEDIA FIRE SAFES

Model	PK-410 Media	PK-420 Media	PK-430 Media	PK-440 Media	PK-480 Media	PK-490 Media
External mm						
height	680	1030	1380	1730	1730	1980
width	670	670	670	670	1160	1220
depth	580	580	580	580	580	580
Internal mm						
height	390	740	1090	1440	1440	1690
width	375	375	375	375	755	815
depth	260	260	260	260	260	260
Volume l	39	73	108	142	284	361
Weight kg	170	230	300	380	625	725

Tested protection for your data media records

- Modern design and wide range of models for multiple data and media storage needs
- Fire protection for data and media records according to NT FIRE 017 - 120 Diskette (fire protection for 120 minutes at temperatures over 1045°C)
- Burglary protection S1 according to European Standard EN 14450 (ECB-S)
- Manufactured in accordance to ISO 9001:2000 quality management system
- Security locking system against burglary, theft and unauthorized access
- Over half a century experience in tested fire security for data and media records

Locking and Security

- The locking mechanism consists of sliding locking bolts on three sides and a locking frame structure on the back panel of the door
- The locking system protects the safe against unauthorized access and keeps the door tightly closed in case of fire
- PK-400 Media fire safes are supplied with ECB-S certified Mauer keylock as standard. Also available with various other electronic code or combination lock models
- S1 burglary certification is only valid for PK-400 Media fire safes supplied with ECB-S certified security locks
- Option for two locks

Design

- Wide range of models and flexible adjustment of the inside fittings enabling multiple use of the media fire safes
- Sealed double door structure for maximum security against fire, heat, magnetism and water
- Standard colour light grey, RAL 7035

Optional inside fittings

- Adjustable shelves
- Pull-out multi-purpose media drawers with dividers

Media and data storage capacity per drawer

Model		PK-410- PK-480	PK-490
		W x D 344 x 251	W x D 377 x 251
DISKS	height	qty	qty
Jaz drives	160	24	24
5.25" Magneto-Optical Disc	160	44	44
CD/DVD	160	68	75
Zip Drives	120	60	62
3.5" Magneto-Optical Disc	100	123	164
CARTRIDGES			
DLT	120	30	30
LTO, LTO Ultrium	120	33	34
Exabyte 8 mm, Travan TR-4	120	54	65
AIT	120	88	100
DAT	100	102	102
DDS	100	138	140

PK-400 Media Fire Safe capacity estimates

Model	PK-410 Media	PK-420 Media	PK-430 Media	PK-440 Media	PK-480 Media	PK-490 Media
DISKS						
Jaz drives	55	105	160	235	470	780
5.25" Magneto-Optical Disc	95	185	280	415	830	920
CD/DVD	160	315	470	705	1405	1640
Zip Drives	190	380	570	760	1515	2355
3.5" Magneto-Optical Disc	390	905	1290	1810	3615	5505
CARTRIDGES						
DLT	90	180	270	360	720	900
LTO, LTO Ultrium	110	220	325	435	865	1345
Exabyte 8 mm, Travan TR-4	195	390	585	780	1560	1820
AIT	310	615	920	1225	2450	3025
DAT	310	715	1020	1430	2860	3810
DDS	435	1010	1440	2020	4035	4995



Kaso Oy, Lyhtytie 2, P.O. Box 27, 00751 Helsinki, Finland
 Tel. +358 9 346 81, fax +358 9 386 0021
 E-mail: sales@kaso.fi
 www.kaso.fi

